


FlexNeon Light

How to cut and connect entry cables

1. Find and locate the cut lines that are every 50mm




Cut lines are in every 50mm with darker marks. Copper plate is visible if you look inside of the cut line


2. Find the polarity before cutting

In every cut line there are + and – symbol marked on the plate but it can be deep inside of the cut line making it hard to read. There are 3 methods you can use:

A. Read the marks if visible



- B. Located the red cable from the entry (this is the positive side) then mark same line throughout the neonflex before cutting.



C. Tab in 24V power to the terminal and find polarity

